



**INSTRUCTIONS FOR USE
BATHROOM ACCESSORIES BY BISK S.A.**

No.	Product category	Procedure
1.	STEEL BASKETS	Wash the product with soap and water and wipe dry. Do not use aggressive or abrasive agents.
2.	STEEL AND PLASTIC SOAP DISPENSERS	Wash the product with soap and water and wipe dry. Do not use aggressive or abrasive agents. Please read and follow the instructions included with the product.
3.	STEEL AND PLASTIC PAPER TOWEL DISPENSERS	Wash the product with soap and water and wipe dry. Do not use aggressive or abrasive agents. Please read and follow the instructions included with the product.
4.	STEEL AND PLASTIC HAND DRYERS	Install and use the product in accordance with the attached instructions and warranty terms. In the event of a failure, contact the service centre (telephone is provided in the warranty card). When performing maintenance on the device, disconnect it from power supply, then wipe it with a damp cloth and wipe it dry. Do not use aggressive or abrasive agents.
5.	STEEL TOILET BRUSHES	Wash the product with soap and water and wipe dry. Please read and follow the instructions included with the product. After disinfecting/washing the container and brush, rinse them under running water. The brush container must not be filled with water or caustic/cleaning agents. Do not use aggressive or abrasive agents when cleaning.
6.	BATHROOM FITTINGS	Wash the product with soap and water and wipe dry. Do not use aggressive or abrasive agents. Follow the operating and assembly instructions included with the product.
7.	METAL BATHROOM ACCESSORIES AND SHOWER SETS	Wash the product with soap and water and wipe dry. Do not use aggressive or abrasive agents.
8.	METAL BATHROOM ACCESSORIES COMBINED WITH WOOD	Clean the wood elements and frequently use wood care products for protection. Wash galvanized and painted metal elements with soapy water and wipe dry. Do not use aggressive or abrasive agents when cleaning.
9.	ACCESSORIES FROM THE "PRO" COLLECTION	Wash the product with soap and water and wipe dry. Do not use aggressive or abrasive agents. Please read and follow the instructions included with the product.
10.	ALL PLASTIC PRODUCTS	Wash the product with soap and water and wipe dry. Do not use aggressive or abrasive agents.
11.	OTHER STAINLESS STEEL AND CHROME STEEL PRODUCTS	Wash the product with soap and water and wipe dry. Do not use aggressive or abrasive agents.

Most of the BISK S.A. products are equipped with individual instruction manuals. Please read and adhere to the provisions of the above-mentioned individual instruction manuals. Instruction manuals are also available on our website www.bisk.eu under the customer support tab.